


QJMOTOR
ALWAYS FORWARD

PARTS CATALOG

STREET CRUISER
SRV-700




F01 CONTROL ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F01-01	40450P530000	LEFT REARVIEW MIRROR ASSEMBLY	1	
F01-02	40031S010000	BALANCER	2	
F01-03	40001K740000	LEFT HANDLEBAR GRIP	1	
F01-04	40500P310002	LEFT COMBINATION SWITCH	1	
F01-05	40101P530001	STEERING HANDLE	1	
F01-06	40600P310001	RIGHT COMBINATION SWITCH	1	
F01-07	40210P280000	RIGHT GRIP ASSEMBLY	1	
F01-08	40480P530000	RIGHT REARVIEW MIRROR ASSEMBLY	1	
F01-09	40300P530000	THROTTLE CABLE ASSEMBLY I	1	
F01-10	40330P530000	THROTTLE CABLE ASSEMBLY II	1	
F01-11	40400P530000	CLUTCH WIRE ASSEMBLY	1	
F01-12	40080P160003	LEFT HANDLE ASSEMBLY	1	
F01-13	40012P130000	REAR VIEW MIRROR RUBBER PLUG	2	
F01-14	B02810602562	SCREW M6×25-8.8-ZG	2	
F01-15	45023P250000	FRONT BRAKE MASTER CYLINDER HOLDER	1	
F01-16	40083P250000	LEFT HANDLE BASE SCREW	1	
F01-17	91090P250000	CLUTCH SWITCH ASSEMBLY	1	
F01-18	41080P160101	CLUTCH LEVER, BLACK	1	
F01-19	B04170600055	SELF LOCKING NUT M6	1	


F02 FORK ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F02-01	B0205080256K	HEXAGON SOCKET HEAD CAP SCREW M8×25	4	
F02-02	43014P010100	STEERING HANDLE LOWER SEAT	2	


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F02-03	08024J000100	SHIM	2	
F02-04	47015P010010	SILENCING PLUG	4	
F02-05	40086P010002	HANDLE POSITIONING STUD	2	
F02-06	43049P800000	FASTENING SCREW OF UPPER CONNECTING PLATE	1	
F02-07	43011P530000	UPPER CONNECTING BOARD	1	
F02-08	B0226080256S	HEXAGON SOCKET FLOWER CYLINDRICAL HEAD SCREW M8×25	6	
F02-09	40089P010100	HANDLE POSITIONING GASKET	2	
F02-10	B04821012552	SELF LOCKING NUT M10×1.25	2	
F02-11	58306P160000	PROTECT RUBBER JACKET	2	
F02-12	43008S010010	FASTENING NUT OF UPPER CONNECTING PLATE	1	
F02-13	43009P260000	NUT	1	
F02-14	43005S010000	DUST RING	2	
F02-15	43130S010000	STEERING BEARING	2	
F02-16	B0226040106S	HEXAGON SOCKET HEAD CAP SCREW M4×10	1	
F02-17	43100P53000Z	LOWER CONNECTING PLATE ASSEMBLY	1	
F02-18	43200P530000	FRONT LEFT SHOCK ABSORBER ASSEMBLY	1	
F02-19	43300P530000	FRONT RIGHT SHOCK ABSORBER ASSEMBLY	1	
F02-20	B0226060306S	HEXAGON SOCKET FLOWER SHAPED CHEESE HEAD SCREW M6×30	2	
F02-21	08029S020300	THIN HEXAGON SOCKET FLOWER FLANGE SCREW M10×1.25×55	4	
F02-22	130015090000	PIN DOWEL	4	
F02-23	45710N490000	FRONT WHEEL SPEED SENSOR	1	
F02-24	43283P100010	GASKET Φ11.5×Φ6×0.4	1	
F02-25	B0226060126S	HEXAGON SOCKET FLOWER SHAPED CHEESE HEAD SCREW M6×12	1	
F02-26	57012P930000	STAINLESS STEEL WIRE CLAMP	1	
F02-27	08002P620001	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×12	1	
F02-28	43021P540000	INSTRUMENT CABLE CLAMP	1	
F02-29	43260N220010	OIL SEAL - 41 x 54 x 11	2	
F02-30	43290N220001	DUST SEAL - 41 x 54.4 x 5.4 x 13.1	2	
F02-31	43204P100011	BOLT	2	
F02-32	B190104170B0	O-RING Φ41.7×Φ2.65	2	
F02-33	43058P530000	DIRECTION TIE TOP SEAT RUBBER PLUG	4	

F03 FRONT WHEEL ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F03-01	44004P530000	FRONT AXLE	1	
F03-02	44016P100100	FRONT WHEEL RIGHT BUSHING	1	
F03-03	08001P32000J	HEXAGON SOCKET FLOWER CYLINDRICAL HEAD SCREW M8×25	12	
F03-04	45030P530000	FRONT BRAKE DISC ASSEMBLY	2	
F03-05	B140108F1620	VACUUM TIRE 130/90-16	1	
F03-07	95950P850000	TIRE PRESSURE SENSOR	1	
F03-08	60200J000001	DUST RING ASSEMBLY	2	
F03-09	B12016020400	ROLLING BEARING 6204-2RS	2	
F03-10	44006P530000	FRONT WHEEL INTERMEDIATE SHAFT SLEEVE	1	
F03-11	45702P160000	FRONT WHEEL SPEED RING GEAR	1	
F03-12	44005P160100	FRONT WHEEL LEFT BUSHING	1	
F03-13	44091P290000	5 GRAMS DYNAMIC BALANCE WEIGHT	5	
F03-14	44100P53000Z	FRONT WHEEL RIM ASSEMBLY	1	


F04 BRAKE ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F04-01	45400P410000	MASTER CYLINDER, FRONT DISC BRAKE	1	
F04-02	45180J000100	SEAL WASHER	9	
F04-03	45037J000200	COUPLING BOLT	2	
F04-04	45240P530000	FRONT HYDRAULIC BRAKE OIL PIPE ASSEMBLY I	1	
F04-05	45270P530000	FRONT HYDRAULIC BRAKE OIL PIPE ASSEMBLY II	1	
F04-06	45250P530000	FRONT HYDRAULIC BRAKE OIL PIPE ASSEMBLY III	1	
F04-07	45021B510000	DUST COVER OF AIR VENT	4	


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F04-08	45019N100100	DEFLATING VALVE	2	
F04-09	45037P150100	OIL PIPE MOUNTING BOLT	1	
F04-10	45037P300200	OIL PIPE MOUNTING BOLT	1	
F04-11	45500P41BG00	FRONT LEFT BRAKE CYLINDER ASSEMBLY	1	
F04-12	45600P41BG00	FRONT RIGHT BRAKE CYLINDER ASSEMBLY	1	
F04-13	45120S010011	FRONT BRAKE PAD ASSY (8PCS/SET)	1 SET	
F04-14	160306030020	HEXAGON TORX BOLT M6×16	1	
F04-15	55140P260000	OIL CUP ASSEMBLY	1	
F04-16	59710P520000	OIL CUP MOUNTING SEAT	1	
F04-17	160306030010	HEXAGON TORX BOLT M6×12	1	
F04-18	55400P530000	REAR OIL PUMP BODY ASSEMBLY	1	
F04-19	55300P180000	REAR BRAKE PRESSURE SWITCH	1	
F04-20	55240P530000	REAR HYDRAULIC BRAKE OIL PIPE ASSEMBLY I	1	
F04-21	55270P530000	REAR HYDRAULIC BRAKE OIL PIPE ASSEMBLY II	1	
F04-22	45700P530000	DUAL CHANNEL ABS ASSEMBLY	1	
F04-23	55037P250100	OIL PIPE MOUNTING BOLT	4	
F04-24	45078P440001	WASHER	10	
F04-25	55500P38BG01	REAR BRAKE CYLINDER ASSEMBLY	1	
F04-26	55110P380001	BRAKE SHOE ASSEMBLY (2PCS/SET)	1 SET	
F04-27	50920S070000	SENSOR WIRE CLIP	10	
F04-28	55019P300100	VENT NOZZLE	2	
F04-29	45023P410000	HANDLE FIXING COVER	1	
F04-30	B02810602562	SCREW M6×25-8.8-ZG	2	
F04-31	45300P410000	FRONT BRAKE SWITCH ASSEMBLY	1	
F04-32	45024P410000	HANDLE FIXING BOLT	1	
F04-33	45020P410000	BRAKE LEVER	1	
F04-34	B04170600055	SELF LOCKING NUT M6	1	
F04-35	45015P180000	DUST COVER OF UPPER SLIDING SHAFT	1	
F04-36	45014P180100	UPPER SLIDING SHAFT	1	
F04-37	45018P180000	LOWER SLIDING SHAFT SLEEVE	1	
F04-38	45017P180100	LOWER SLIDING SHAFT	1	

F05 MUFFLER ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F05-01	47100P530012	MUFFLER ASSY	1	
F05-02	B0407080005H	NUT M8	4	
F05-03	08015P620013	BOLT M10×1.25×135	1	
F05-04	47800P190000	GASKET AS-EXHAUST	2	
F05-05	319026280000	OXYGEN SENSOR	2	
F05-06	47760P52MM00	COVER AS-TRIM, YELLOW MM	1	
F05-07	B1304060160A	COMBINATION SCREW M6×16	4	
F05-08	27097505001X	BUSHING	2	
F05-09	65616L430000	PROTECTIVE PLATE RUBBER PAD	2	
F05-10	47023P52MM02	DECORATIVE COVER	1	
F05-11	47016P830000	INSULATION GASKET	2	
F05-12	65764N290000	SPONGE PAD	2	

F06 AIR CLEANER ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F06-01	49100P810100	AIR FILTER ASSEMBLY	1	
F06-02	49200P810000	FILTER ELEMENT ASSEMBLY	1	
F06-03	49016N070001	STAINLESS STEEL CLAMP 40-60	2	
F06-04	49805J000200	PLATE CLAMP Ø18.5×10×1	6	
F06-05	49025P810000	EXHAUST GAS RECOVERY PIPE	1	
F06-06	49809P530000	CONNECTING PIPE BETWEEN ELECTRICALLY CONTROLLED AIR MAKEUP VALVE & AIR FILTER	1	
F06-07	58790P530000	RECTIFIER BRACKET	1	
F06-08	B0109060146H	HEXAGON FLANGE BOLT M6×14	2	
F06-09	49760P090000	ELECTRICALLY CONTROLLED AIR MAKEUP VALVE	1	
F06-10	49808P530000	CONNECTING PIPE BETWEEN ELECTRICALLY CONTROLLED AIR MAKEUP VALVE & CYLINDER HEAD	1	
F06-11	49912K670000	CARBON CANISTER ASSEMBLY	1	
F06-12	50306T450300	PLATE CLAMP Ø8	9	
F06-13	49902P520000	CONNECTING PIPE BETWEEN DUMP VALVE AND CARBON CANISTER	1	
F06-14	50260T730003	VEHICLE DOWN SENSOR	1	
F06-15	49902P600000	CONNECTING PIPE BETWEEN DUMP VALVE & CARBON CANISTER	1	
F06-16	50307J140302	PLATE CLAMP Ø10	3	
F06-17	49922P520000	CONNECTING PIPE BETWEEN CARBON CANISTER & SOLENOID VALVE	1	
F06-18	49710N070001	CARBON CANISTER SOLENOID VALVE	1	
F06-19	49923P530000	CONNECTING PIPE BETWEEN SOLENOID VALVE & THROTTLE BODY	1	
F06-20	49924P810000	CONNECTING PIPE II BETWEEN SOLENOID VALVE & THROTTLE BODY	1	
F06-21	50008B420000	TEE	1	
F06-22	49925P810000	CONNECTING PIPE III BETWEEN SOLENOID VALVE & THROTTLE BODY	1	
F06-23	57050P530000	CARBON PIPE SOLENOID VALVE BRACKET	1	
F06-24	160306030010	HEXAGON TORX BOLT M6×12	2	
F06-25	49361P530000	AIR FILTER MOUNTING BRACKET	1	
F06-26	08002P620003	HEXAGON SOCKET FLANGE SCREW M6×20	1	
F06-27	65624L750000	CLAMP NUT M6	1	
F06-28	57437P810000	FLASHER FIXING BRACKET	1	
F06-29	08002P620001	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×12	1	


F07 FUEL TANK ASSY.



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F07-01	B0226050306A	HEXAGON SOCKET HEAD CAP SCREW M5x30	3	
F07-02	B0226050146A	HEXAGON SOCKET HEAD CAP SCREW M5x14	3	
F07-03	B0226080356S	HEXAGON SOCKET HEAD SCREW M8x35	1	


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F07-04	50014J410100	RUBBER PAD LINER	1	
F07-05	50018V030000	OIL TANK BUFFER RUBBER	1	
F07-06	65617P420000	RUBBER PAD II	2	
F07-07	65616P420000	RUBBER PAD I	2	
F07-08	50100P53007Z	TANK ASSEMBLY, BLACK BW, WITH STICKER"	1	FOR SHINING BLACK BIKE
F07-08	50100P53008Z	TANK ASSEMBLY, MATT BLACK BG, WITH STICKER"	1	FOR MATT BLACK BIKE
F07-08	50100P53009Z	TANK ASSEMBLY, GREEN U8, WITH STICKER"	1	FOR GREEN BIKE
F07-09	160306030050	HEXAGON TORX BOLT M6×25	2	
F07-10	08023J000100	TANK MOUNTING WASHER	2	
F07-11	50014P250010	RUBBER PAD LINER	2	
F07-12	50005P250000	FRONT MOUNTING PAD OF OIL TANK	2	
F07-13	50808P250010	OIL LEVEL SENSOR PORT RUBBER PAD	1	
F07-14	50800P530000	OIL LEVEL SENSOR	1	
F07-15	08012P620001	HEX. SOCKET FLOWER RECESSED HEXAGON FLANGE BOLT M5×16	10	
F07-16	50400P530000	FUEL PUMP ASSEMBLY	1	
F07-17	50070P530000	HIGH PRESSURE OIL PIPE ASSEMBLY I	1	
F07-18	50080P530000	HIGH PRESSURE OIL PIPE ASSEMBLY II	1	
F07-19	50340N070000	FILTER ASSEMBLY	1	
F07-20	50391N070010	FILTER JACKET	1	
F07-21	B1701010500H	STEEL WIRE CLAMP Ø10.5	1	
F07-22	50012K980000	PIPE Ø7×2	1	
F07-23	65618N490000	SPONGE PAD	2	
F07-25	05532P53BG00	TANK LEFT DECAL - MATT BLACK BG	1	FOR MATT BLACK BIKE
F07-25	05532P53BW00	TANK LEFT DECAL - BLACK BW	1	FOR SHINING BLACK BIKE
F07-25	05532P53JN00	TANK LEFT DECAL - GREEN U8	1	FOR GREEN BIKE
F07-26	05533P53BG00	TANK RIGHT DECAL - MATT BLACK BG	1	FOR MATT BLACK BIKE
F07-26	05533P53BW00	TANK RIGHT DECAL - BLACK BW	1	FOR SHINING BLACK BIKE
F07-26	05533P53JN00	TANK RIGHT DECAL - GREEN U8	1	FOR GREEN BIKE
F07-27	05534P53BG00	DECAL IN THE MIDDLE OF THE TANK - MATT BLACK BG	1	FOR MATT BLACK BIKE
F07-27	05534P53BW00	DECAL IN THE MIDDLE OF THE TANK - BLACK BW	1	FOR SHINING BLACK BIKE
F07-27	05534P53JN00	DECAL IN THE MIDDLE OF THE TANK - GREEN U8	1	FOR GREEN BIKE

F08 REAR SWINGING ARM ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F08-01	54004P060001	REAR AXLE	1	
F08-02	53005P520000	REAR SWING ARM LEFT BUSHING	2	
F08-03	53220P370000	REAR SWING ARM OIL SEAL ASSEMBLY	3	
F08-04	B1210H262001	NEEDLE ROLLER BEARING NK26 / 20	3	
F08-05	53006P520000	RIGHT INNER BUSHING OF REAR SWING ARM	1	
F08-06	B12016000400	ROLLING BEARING 6004	1	
F08-07	B08000004201	CIRCLIP FOR HOLE Ø42	1	
F08-08	53220S010000	REAR SWING ARM SEAL RING	1	
F08-09	53007P520000	RIGHT OUTER BUSHING OF REAR SWING ARM	1	
F08-10	08051P100100	SELF LOCKING NUT M20×1.5	1	
F08-11	53100PAU000Z	REAR SWING ARM ASSEMBLY	1	
F08-12	53004P530000	CHAIN GUARD BLOCK	1	
F08-13	08003P620000	HEXAGON SOCKET FLOWER FLANGE STEP SCREW M6×15	6	
F08-14	B0226060306S	HEXAGON SOCKET FLOWER SHAPED CHEESE HEAD SCREW M6×30	2	
F08-15	53021P250000	SUPPORT SLEEVE	2	
F08-16	08002P300010	CHAIN ADJUSTING SCREW M8	2	
F08-17	B0407080005H	NUT M8	2	
F08-18	53231P360000	CHAIN ADJUSTING BLOCK	2	
F08-19	60101PAU0000	CHAIN COVER	1	
F08-20	57015P520000	RUBBER PLUG FOR THREADED HOLE OF FRONT PEDAL BRACKET	1	
F08-21	08002P620000	HEXAGON LOBULAR FLANGE SCREW M6×8	1	

F09 REAR SWINGING ARM ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F09-01	08013V030000	BOLT M10×67	4	
F09-02	53430P520001	REAR SWING ARM LINK SEAL RING	6	
F09-03	53030P520001	NEEDLE BEARING Φ17×Φ24×25	6	
F09-04	53402P520000	INTERMEDIATE SHAFT SLEEVE OF REAR SWING ARM LINK	3	
F09-05	53304P520001	REAR SWING ARM LINK ROCKER ARM	1	
F09-06	B04171012548	ALL METAL HEXAGON FLANGE LOCK NUT M10	4	
F09-07	53440P520000	REAR SWING ARM LINK HANGING PLATE ASSEMBLY	1	
F09-08	53441P520100	REAR SWING ARM LINK HANGING PLATE	1	
F09-09	08013P290000	REAR SHOCK ABSORBER UPPER FIXING BOLT	1	
F09-10	63800P530001	REAR SHOCK ABSORBER ASSEMBLY	1	
F09-11	B0417121254H	SELF LOCKING NUT M12×1.25	1	

F10 REAR WHEEL ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F10-01	54004P060001	REAR AXLE	1	
F10-02	B04821012552	NUT M10×1.25	6	
F10-03	54005P060000	REAR WHEEL BUSHING	1	
F10-04	60002P810000	SPROCKET 46	1	
F10-05	60310P530000	CHAIN 520VE-1×120	1	
F10-06	60001P810000	CHAIN HUB ASSEMBLY	1	
F10-07	60016P810000	BOLT M10×1.25×40	6	
F10-08	54024P160001	REAR WHEEL BUFFER BLOCK	5	
F10-09	60006P160000	CHAIN DRIVE SHAFT SLEEVE	1	
F10-10	B12016030400	ROLLING BEARING 6304-2RS	2	
F10-11	54006P160000	REAR WHEEL INTERMEDIATE SHAFT SLEEVE	1	
F10-13	95950P850000	TIRE PRESSURE SENSOR	1	
F10-14	B140110E1620	VACUUM TIRE 150/80-16	1	
F10-15	54300P160000	OIL SEAL	2	
F10-16	55030P530000	REAR BRAKE DISC ASSEMBLY	1	
F10-17	45036P520100	LIQUID BRAKE DISC MOUNTING SCREW M8×24	4	
F10-18	55401P530000	REAR HYDRAULIC BRAKE HANGING PLATE	1	
F10-19	55710N490000	REAR WHEEL SPEED SENSOR	1	
F10-20	160306030010	BOLT M6×12	1	
F10-21	08051P100100	NTU M20×1.5	1	
F10-22	B12016020500	ROLLING BEARING 6205-2RS	2	
F10-23	54100PAU000Z	RIM AS-REAR WHEEL	1	
F10-24	43283P100010	GASKET Φ11.5×Φ6×0.4	1	
F10-25	B0700000080H	SPRING WASHER 8	2	
F10-26	B0226080256S	HEXAGON SOCKET FLOWER CYLINDRICAL HEAD SCREW M8×25	2	
F10-27	44091P290000	5 GRAMS DYNAMIC BALANCE WEIGHT	5	

F11 FRONT FRAME ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F11-01	65533P520000	FRAME TRIM COVER II	2	
F11-02	160306030150	HEXAGON TORX BOLT M8×25	2	
F11-03	58420P520000	FRONT CONNECTING PIPE ASSEMBLY OF FRAME	1	
F11-04	B0159101706H	HEXAGON FLANGE BOLT M10×1.25×170	2	
F11-05	B0417101254H	SELF LOCKING NUT M10×1.25	2	
F11-06	B0109080456H	HEXAGON FLANGE BOLT M8×45	2	
F11-07	58320P530000	WELDING ASSEMBLY OF LEFT POWER HANGING PLATE	1	
F11-08	B0159100506H	BOLT M10×1.25×50	2	
F11-09	B0417080004H	SELF LOCKING NUT M8	4	
F11-10	58330P530000	WELDING ASSEMBLY OF RIGHT POWER HANGING PLATE	1	
F11-11	B0109080356H	HEXAGON FLANGE BOLT M8×35	2	
F11-12	57060P090000	ENGINE FRONT BUFFER BUSHING	2	
F11-13	65618J000000	GUARD RUBBER PAD C	2	
F11-14	58760P520000	BATTERY HOLDER	1	
F11-15	B0226060126S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M6×12	6	
F11-16	B100432007P0	POP RIVETS 3.2×7	2	
F11-18	57100P530000	FRAME WELDING ASSEMBLY	1	
F11-19	57545P520000	POWER LOCK MOUNTING BASE	1	
F11-20	08014P620009	HEX. FLANGE BOLT WITH INNER HEXAGON FLOWER SHAPED RECESS M8×65	2	
F11-21	160306030050	HEXAGON TORX BOLT M6×25	2	
F11-22	27097505001X	BUSHING	2	
F11-23	65616L430000	GUARD RUBBER PAD	3	
F11-24	51070PAU0000	FRONT SEAT CUSHION LIMIT PLATE WELDING ASSEMBLY	1	
F11-25	B0201060252H	SCREW M6×25	2	
F11-26	58900K980000	CUSHION CABLE ASSEMBLY	1	
F11-27	57980PAU0000	LEFT CONNECTING SEAT OF REAR TAIL COVER	1	
F11-28	57990PAU0000	RIGHT CONNECTING SEAT OF REAR TAIL COVER	1	
F11-29	08002P620001	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×12	6	
F11-30	51220PAU0000	SEAT CUSHION STRAP ASSEMBLY	1	
F11-31	B0401101255H	NUT M10×1.25	2	
F11-32	65684P530000	THERMAL CONDUCTIVE COVER INSULATION SPONGE	2	

F12 FRAME TRIM PANEL ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F12-01	65691P53VB00	FRAME LEFT TRIM PANEL, GRAY VB	1	
F12-02	08003P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE STEP SCREW M6×15	8	
F12-03	05518PAU0000	ALUMINUM PLATE OF LEFT TRIM PANEL OF FRAME	1	
F12-04	65693P530000	LEFT TRIM PANEL OF ENGINE	1	
F12-05	65618J130001	GUARD RUBBER PAD	6	
F12-06	65532PAU0000	FRAME TRIM COVER I	1	
F12-07	65532P520000	FRAME TRIM COVER I	1	
F12-08	65692P53VB00	FRAME RIGHT TRIM PANEL, GRAY VB	1	
F12-09	05519PAU0000	ALUMINUM PLATE OF RIGHT TRIM PANEL OF FRAME	1	
F12-10	65694P530000	ENGINE RIGHT TRIM PANEL	1	
F12-11	65683P530000	HEAT CONDUCTION HOOD	1	
F12-12	65616L430000	PROTECTIVE PLATE RUBBER PAD	2	
F12-13	65684P530000	THERMAL CONDUCTIVE COVER INSULATION SPONGE	2	

F13 SIDE STAND ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F13-01	57005PAD0000	SINGLE SUPPORT FIXING BOLT	1	
F13-02	58701P530000	SINGLE SUPPORT	1	
F13-03	08003P620000	HEXAGON FLANGE STEP SCREW M6x15	2	
F13-04	91171P290000	DECORATIVE COVER OF SINGLE SUPPORT FLAMEOUT SWITCH	1	
F13-05	B0226050146S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M5x14	2	
F13-06	91170P160100	SINGLE SUPPORT FLAMEOUT SWITCH	1	
F13-07	58730P290000	DECORATIVE COVER MOUNTING BASE	1	
F13-08	B0402080001H	HEXAGON THIN NUT M8	1	
F13-09	57003P250000	SPRING, OUTER	1	
F13-10	57004S010000	SPRING, INNER	1	

F14 PEDALING ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F14-01	58204P530000	FRONT LEFT PEDAL BRACKET MOUNTING PLATE	1	
F14-02	57015P520000	RUBBER PLUG FOR THREADED HOLE OF FRONT PEDAL BRACKET	4	
F14-03	08001N510000	THIN HEXAGONAL FLANGE SCREW M8×35	1	
F14-04	65613P260000	SHIELD LINER	3	
F14-05	65617H010010	RUBBER SLEEVE II	3	
F14-06	08024J000100	SHIM	1	
F14-07	08014P620005	HEX FLOWER SHAPED CONCAVE HEX FLANGE BOLT M8×40	4	
F14-08	B0109060426H	HEXAGON FLANGE BOLT M6×42	2	
F14-09	B0702000060H	WASHER Ø6	4	
F14-10	40706S040000	M6 LEFT JOINT	1	
F14-11	B04800600052	NUT M6-8-ZG	1	
F14-12	B0226080306S	HEXAGON SOCKET FLOWER CYLINDRICAL HEAD SCREW M8×30	1	
F14-13	08380P530001	SHIFT LEVER ASSEMBLY	1	
F14-14	52018B590010	REAR SHELF INSTALLATION SHAFT SLEEVE II	2	
F14-15	58226P530001	LEFT FRONT PEDAL BRACKET	1	
F14-16	58217P260000	PEDAL MOUNTING PIN	1	
F14-17	58220N490000	LEFT FRONT PEDAL ASSEMBLY	1	
F14-18	58222S010100	PEDAL SPRING	1	
F14-19	B0882000050A	RETAINING RING Ø5	1	
F14-20	08381P360000	SHIFT LEVER I	1	
F14-21	08383P530000	SHIFT LEVER II	1	
F14-22	08051S040010	LEFT NUT M6	1	
F14-23	08375S010000	KNOT	1	
F14-24	50031S010010	FRONT FIXED SPACER SLEEVE	2	
F14-25	08386P100001	SHIFT LEVER MOUNTING BASE	1	
F14-26	B0226060206S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M6×20	1	
F14-27	B04810600052	NUT M6×1	1	

F15 PEDALING ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F15-01	58404P530000	FRONT RIGHT PEDAL BRACKET MOUNTING PLATE	1	
F15-02	57015P520000	RUBBER PLUG FOR THREADED HOLE OF FRONT PEDAL BRACKET	4	
F15-03	08001N510000	THIN HEXAGONAL FLANGE SCREW M8×35	1	
F15-04	65613P260000	SHIELD LINER	3	
F15-05	65617H010010	RUBBER SLEEVE II	3	
F15-06	08024J000100	SHIM	1	
F15-07	08014P620005	HEX. FLOWER SHAPED CONCAVE HEX. FLANGE BOLT M8×40	4	
F15-08	52018B590010	REAR SHELF INSTALLATION SHAFT SLEEVE II	2	
F15-09	40273P250000	UPPER SPRING PIN	1	
F15-10	40702P520000	BRAKE PEDAL RETURN SPRING	1	
F15-11	58246P520002	FRONT RIGHT PEDAL BRACKET	1	
F15-12	B0226080256S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M8×25	2	
F15-13	58217P260000	PEDAL MOUNTING PIN	2	
F15-14	58240N490000	RIGHT FRONT PEDAL ASSEMBLY	1	
F15-15	58222S010100	PEDAL SPRING	1	
F15-16	B0882000050A	RETAINING RING Ø5	2	
F15-17	58216S010000	SHIM	1	
F15-18	B0900250241H	COTTER PIN Ø2.5×24	1	
F15-19	40712P520001	BRAKE PEDAL	1	
F15-20	58511S010001	SELF LUBRICATING BUSHING	1	
F15-21	40706P250102	MOUNTING SCREW OF REAR BRAKE PEDAL	1	
F15-22	B0703000080H	WASHER 8	1	
F15-23	B090408020BH	PIN 8×20	1	

F16 PEDALING ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F16-01	53301P520000	LEFT BRACKET OF REAR SWING ARM	1	
F16-02	B0276100556P	SCREW M10×1.25×55	2	
F16-03	B0276100456P	SCREW M10×1.25×45	2	
F16-04	53018PAU0000	REAR SWING ARM SUPPORT TRIM COVER	2	
F16-05	58450PAU0000	LEFT REAR PEDAL BRACKET ASSEMBLY	1	
F16-06	08015P620002	BOLT M10×1.25×25	2	
F16-07	08015P620003	BOLT M10×1.25×30	2	
F16-08	58217P260000	PEDAL MOUNTING PIN	2	
F16-09	58266P520000	REAR LEFT PEDAL BRACKET	1	
F16-10	B0226080256S	BOLT M8×25	4	
F16-11	B0882000050A	WASHER Ø5	2	
F16-12	58260P26001Z	LEFT REAR PEDAL COMBINATION	1	
F16-13	53302P520000	RIGHT BRACKET OF REAR SWING ARM	1	
F16-14	58470P520000	RIGHT REAR PEDAL BRACKET ASSEMBLY	1	
F16-15	58286P520000	REAR RIGHT PEDAL SUPPORT	1	
F16-16	58280P26001Z	RIGHT REAR PEDAL COMBINATION	1	
F16-17	57941PAU0000	MOUNTING PLATE OF LEFT TRIM PANEL OF FRAME	1	
F16-18	160306030010	BOLT M6×12	1	
F16-19	65618J000000	RUBBER PAD C OF GUARD BOARD	1	

F17 FRONT FENDER ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F17-01	65101PBDBG00	FRONT FENDER, MATT BLACK BG"	1	FOR MATT BLACK BIKE
F17-01	65101PBDBW00	FRONT FENDER, BLACK BW"	1	FOR SHINING BLACK BIKE
F17-01	65101PBDU800	FRONT FENDER, GREEN U8"	1	FOR GREEN BIKE
F17-02	08002P620004	HEXAGON SOCKET FLANGE SCREW M6×25	4	
F17-03	27097505001X	BUSHING	4	
F17-04	65616L430000	GUARD RUBBER PAD	4	
F17-05	B0417060004H	SELF LOCKING NUT M6	4	
F17-06	65151P370100	FRONT MUDBOARD SUPPORT	2	
F17-07	B0226050146A	HEXAGON SOCKET HEAD CAP SCREW M5x14	4	
F17-08	65141P53MM00	LEFT MOUNTING SEAT OF FRONT MUDBOARD, YELLOW MM	1	
F17-09	08002P620003	HEXAGON SOCKET FLANGE SCREW M6×20	4	
F17-10	86300P090000	FRONT REFLECTOR	2	
F17-11	65151P53MM00	RIGHT MOUNTING SEAT OF FRONT MUDBOARD, YELLOW MM	1	

F18 LIGHT & SPEEDOMETER ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F18-01	70000P530004	INSTRUMENT ASSEMBLY	1	
F18-02	70078P530001	INSTRUMENT SUPPORT	1	
F18-03	B0417050004H	ALL METAL HEXAGON FLANGE LOCK NUT M5	3	
F18-04	08002P620003	HEXAGON SOCKET FLOWER FLANGE SCREW M6×20	7	
F18-05	57312P530000	USB MOUNTING BOARD	1	
F18-06	92950L790001	CAR USB CHARGER	1	
F18-07	65203PBDBG00	HEADLAMP SHIELD, BLACK BG	1	
F18-08	80000PBD0000	HEADLAMP	1	
F18-09	27097505001X	BUSHING	5	
F18-10	65616L430000	RUBBER PAD OF GUARD PLATE	8	
F18-11	65244P53MM00	HEADLAMP LEFT TRIM PANEL, YELLOW MM	1	
F18-12	08002P620004	HEXAGON SOCKET FLOWER FLANGE SCREW M6×25	4	
F18-13	08002P620005	HEXAGON SOCKET FLOWER FLANGE SCREW M6×30	2	
F18-14	81100P530001	REAR LEFT TURN SIGNAL LAMP	1	
F18-15	81300P530001	REAR RIGHT TURN SIGNAL LAMP	1	
F18-16	65245P53MM00	HEADLAMP RIGHT TRIM PANEL, YELLOW MM	1	
F18-17	B0702000050H	WASHER 5	3	

F19 OIL TANK GUARD ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F19-01	65671PAUVB00	OIL TANK FRONT GUARD	1	
F19-02	08002P620100	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×8	2	
F19-03	50116P520000	DECORATIVE SLEEVE OF MIDDLE GUARD PLATE OF OIL TANK	1	
F19-04	08003P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE STEP SCREW M6×15	2	
F19-05	08002P620004	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×25	2	
F19-06	08513P250010	INSTALL SPACER ON HEADLIGHT	2	
F19-07	65821S010000	RUBBER BLOCK	2	
F19-08	65673PAU0000	LEFT TRIM PANEL OF FUEL TANK	1	
F19-09	08001P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M5×12	2	
F19-10	65624P160000	CLIP NUT M5	2	
F19-11	65831P440000	PLASTIC CLIP	2	
F19-12	65674PAU0000	FUEL TANK RIGHT TRIM PANEL	1	

F20 TAIL COVER ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F20-01	65901PAU009Z	REAR TAIL COVER, BLACK BW, WITH STICKER"	1	FOR SHINING BLACK BIKE
F20-01	65901PAU010Z	REAR TAIL COVER, MATT BLACK BG, WITH STICKER"	1	FOR MATT BLACK BIKE
F20-01	65901PAU017Z	REAR TAIL COVER, GREEN U8, WITH STICKER"	1	FOR GREEN BIKE
F20-02	08002P620004	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×25	1	
F20-03	08513P250010	INSTALL SPACER ON HEADLIGHT	1	
F20-04	65821S010000	RUBBER BLOCK	1	
F20-05	08001P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M5×12	10	
F20-06	65624P160000	CLIP NUT M5	10	
F20-07	65911PAU011Z	LEFT TRIM PANEL OF REAR TAIL COVER, GRAY VB, WITH STICKER	1	
F20-08	65912PAU011Z	RIGHT TRIM PANEL OF REAR TAIL COVER, GRAY VB, WITH STICKER	1	
F20-09	65606PAU0000	REAR TAIL COVER CONNECTING PLATE	1	
F20-10	51100P530000	FRONT SEAT CUSHION ASSEMBLY	1	
F20-11	51200PAU0020	REAR SEAT CUSHION ASSEMBLY	1	
F20-12	65618N490000	SPONGE PAD	2	
F20-13	05571P53BG00	REAR COVER DECAL - MATT BLACK BG	1	FOR MATT BLACK BIKE
F20-13	05571P53BW00	REAR COVER DECAL - BLACK BW	1	FOR SHINING BLACK BIKE
F20-13	05571P53JN00	REAR COVER DECAL - GREEN U8	1	FOR GREEN BIKE
F20-14	05573P530001	REAR REAR HOOD LEFT TRIM PANEL DECAL	1	
F20-15	05574P530001	REAR REAR HOOD RIGHT TRIM PANEL DECAL	1	

F21 REAR FENDER ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F21-01	65731PAU0000	REAR INNER FENDER	1	
F21-02	08001P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M5×12	13	
F21-03	65624P160000	CLIP NUT M5	13	
F21-04	08002P620001	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×12	8	
F21-05	65803S010010	CARD NUT M6	4	
F21-06	57403PAU0000	STARTING RELAY MOUNTING PLATE	1	
F21-07	65770PAU0000	WELDING ASSEMBLY OF REAR FENDER BRACKET	1	
F21-08	08003P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE STEP SCREW M6×15	1	
F21-09	65701PAU0000	REAR FENDER	1	
F21-10	81500PAU0000	REAR LEFT TURN SIGNAL LAMP	1	
F21-11	81700PAU0000	REAR RIGHT TURN SIGNAL LAMP	1	
F21-12	58507H170000	MIDDLE SUPPORT BUFFER BLOCK	1	
F21-13	86500L930000	REAR REFLECTOR	1	
F21-14	82500T480011	REAR LICENSE PLATE LAMP	1	
F21-15	B0507420130H	SELF TAPPING SCREW ST4.2×13	1	
F21-16	08202G120000	FRONT LICENSE PLATE COVER	1	
F21-17	160306030010	HEXAGON TORX BOLT M6×12	2	
F21-18	B0407060005H	NUT M6	2	
F21-19	B0703000050H	FLAT WASHER Ø5	2	
F21-20	B0700000050H	SPRING WASHER Ø5	2	
F21-21	B0402050001H	HEXAGON THIN NUT M5	2	
F21-22	82000PAU0000	TAILLIGHT	1	

F22 COOLING SYSTEM ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F22-02	06103P810000	WATER PIPE PLATE CLAMP Ø30	4	
F22-03	06251P530000	ENGINE OUTLET PIPE	1	
F22-04	65821S010000	RUBBER BLOCK	3	
F22-05	08011P360000	INSTALLATION BOLTS OF WATER TANK TRIM PANEL	4	
F22-06	06211P530000	ENGINE WATER INLET PIPE	1	
F22-07	65681P53001Z	LEFT TRIM PANEL OF WATER TANK, BLACK N9, WITH STICKER	1	
F22-08	08003P620000	HEXAGON SOCKET FLOWER SHAPED FLANGE STEP SCREW M6×15	4	
F22-09	65682P53001Z	RIGHT TRIM PANEL OF WATER TANK, BLACK N9, WITH STICKER	1	
F22-10	160306030050	HEXAGON TORX BOLT M6×25	1	
F22-11	27097505001X	BUSHING	1	
F22-12	50376S010000	CLAMP Ø10	2	
F22-13	06101P530000	WATER INLET PIPE OF EXPANSION KETTLE	1	
F22-14	06110P530001	EXPANSION KETTLE	1	
F22-15	160306030020	HEXAGON TORX BOLT M6×16	2	
F22-16	B0702000060H	WASHER Ø6	2	
F22-17	06113P180000	EXPANSION KETTLE LID	1	
F22-18	50307J140302	PLATE CLAMP	1	
F22-19	06133M230000	KETTLE OVERFLOW PIPE	1	
F22-20	06112P530000	EXPANSION KETTLE DECORATIVE COVER	1	
F22-21	B02830500862	SCREW M5×8	2	
F22-22	270265050000	WATER FILLER CAP SUBASSEMBLY	1	
F22-23	279026350000	FAN ASSEMBLY	1	
F22-24	279136600010	WATER TANK WELDING ASSEMBLY	1	
F22-25	05571PAUMK00	TANK LEFT DECORATIVE PANEL DECAL	1	
F22-26	05572PAUMK00	TANK RIGHT DECORATIVE PANEL DECAL	1	

F23 ELECTRICAL EQUIPMENT ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F23-01	95100P160001	HORN	1	
F23-02	B0226080166S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M8×16	2	
F23-03	299066570000	RECTIFIER	1	
F23-04	160306030070	HEXAGON TORX BOLT M6×30	2	
F23-05	91210N300000	ROLL OVER SENSOR	1	
F23-06	98901S010000	SENSOR RUBBER	1	
F23-07	08002P620003	HEXAGON SOCKET FLOWER SHAPED FLANGE SCREW M6×20	2	
F23-08	27097505001X	BUSHING	2	
F23-09	70168N290000	GUARD RUBBER PAD	2	
F23-10	58661P530000	ABS BRACKET	1	
F23-11	58752P250000	BATTERY SPONGE PAD	5	
F23-12	57089P160000	FUSE BOX BRACKET	1	
F23-13	B0507420130H	SELF TAPPING SCREW ST4.2×13	1	
F23-14	AC-TTZ14S (HW)	BATTERY VRLA 12V11.2 AH/10HR	1	
F23-15	94000S010000	STARTING RELAY	1	
F23-16	57460P520000	ECU MOUNTING BASE	1	
F23-17	B0226060126S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M6×12	3	
F23-18	96030N420000	DOUBLE HEAD BUCKLE	3	
F23-19	92039S010000	RELAY	5	
F23-20	96C00P364500	ECU	1	
F23-21	B0226060146S	HEXAGON SOCKET TORX CHEESE HEAD SCREW M6×14	3	
F23-22	59411P530000	SMALL RELAY MOUNTING PLATE	1	
F23-23	92150P090000	CAPACITOR ASSEMBLY	1	
F23-24	59521PAU0000	CAPACITOR MOUNTING PLATE	1	
F23-25	96400TA70100	FLASHER	1	
F23-26	92059P060000	SMART CONTROLLER TO PLUG-IN	1	
F23-27	B0109080126H	BOLT M8×12	1	
F23-28	96007B720000	IGNITER SLEEVE	1	

F24 ELECTRICAL EQUIPMENT ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F24-01	92000P530003	CABLE ASSEMBLY	1	
F24-02	92200P530000	POWER CORD	1	
F24-03	92300P530000	MOTOR WIRE	1	
F24-04	92500P530000	GROUND WIRE	1	
F24-05	96001P360000	BAND 5x210	10	
F24-06	96003P360000	BAND 5x300	12	
F24-07	96700K060000	ACTUATING DIODE	2	
F24-08	02120J690000	ON BOARD TOOL STRAP	1	
F24-09	08010N350000	GROUNDING BOLT ASSEMBLY	3	
F24-10	96031P600000	SHEET METAL BUCKLE	4	
F24-11	96031N350000	BUCKLE 1.5 SERIES	3	
F24-12	96032N350000	BUCKLE 2.3 SERIES	3	
F24-13	65508P290000	EDGE BANDING	1	
F24-14	58430J000000	CLAMP ASSEMBLY	5	
F24-15	88000P520001	SLEEVE LOCK	1	
F24-17	88900P560000	KEY	1	
F24-19	88800N290000	CUSHION LOCK	1	
F24-20	58800S010000	SEAT CUSHION LOCK SEAT	1	
F24-21	96820P060000	MINI FUSE 15A	5	
F24-22	96810P060000	MINI FUSE 10A	1	
F24-23	96003P250000	FLEXIBLE CABLE CLAMP	2	
F24-24	96001L790000	TOOTHED PUSHING CLAMP	7	
F24-25	59481PAU0000	GEAR CONVERTER BRACKET	1	
F24-26	160306030020	HEXAGON FLANGE BOLT M6×16	1	

F25 ENGINE ATTACHMENT ASSY.




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
F25-02	289016580010	THROTTLE BODY ASSY	1	
F25-03	289116600000	INJECTOR ASSEMBLY	1	
F25-04	16945660MM01	REAR COVER AS-LH	1	
F25-05	B0107060256H	HEXAGONAL FLANGE BOLT M6×25	2	

E01 CYLINDER COVER ASSEMBLY




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E01-01	109026600000	CYLINDER HEAD COVER GASKET	1	
E01-02	10901660BG01	CYLINDER HEAD COVER	1	
E01-03	109396600000	CYLINDER HEAD COVER BOLT SEALING RING	4	
E01-04	109326600000	CYLINDER HEAD COVER BOLT	4	
E01-05	96200P740000	HIGH PRESSURE PACK	2	
E01-06	B0107060186H	BOLT M6×EIGHTEEN	2	
E01-07	58430J000000	CLAMP ASSEMBLY	1	
E01-08	10930660BG01	CHECK VALVE COVER	1	
E01-09	110066030000	REED VALVE SUBASSEMBLY	1	
E01-10	109476580000	HIGH PRESSURE PACK PLATE	1	
E01-11	130015090000	POSITIONING SLEEVE	2	
E01-12	109406600000	SPARK PLUG HOLE SEALING RING	2	

E02 CYLINDER HEAD




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E02-01	109216600000	CYLINDER HEAD BOLT	1	
E02-02	120015090000	OIL SEAL SYS. VALVE	6	
E02-03	120096090000	GASKET 10.5×19.8×2	6	
E02-04	109186600000	RUBBER	1	
E02-05	B0205060306H	SCREW M6×30	2	
E02-06	160131170000	WASHER 6	2	
E02-07	10004609001X	SHORT STUDS	4	
E02-08	10905660BG01	CYLINDER HEAD MACHINED COMPONENTS	1	
E02-09	109076600000	SEAL WASHER ASSY	1	
E02-10	B090108014B0	PARALLEL PIN	2	
E02-11	270014590000	WATER TEMPERATURE SENSOR	1	
E02-12	49016N070001	CLAMP 40-60	2	
E02-13	119016600010	VALVE RETAINER ASSY	2	
E02-14	B0205060166H	SCREW M6×16	4	
E02-15	160306030030	BOLT M6×20	3	
E02-16	10944660BG01	THERMOSTAT HOSING	1	
E02-17	109085240000	O RING 45×2.65	1	
E02-18	279276600000	WATER THERMOSTAT	1	
E02-19	-	SPARK PLUG	2	
E02-20	109206600000	CYLINDER HEAD BOLT	4	
E02-21	109226600000	CYLINDER HEAD BOLT	1	
E02-22	119126600000	O RING	2	

E03 CYLINDER ASSY



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E03-01	B0205060306H	SCREW M6×30	2	
E03-02	13903660BG01	CYLINDER	1	
E03-03	130016600000	BOLT M8×43	1	
E03-04	100054460000	SPACER	1	
E03-05	130046600000	NUT	1	
E03-06	120096090000	SPACER 10.5×19.8×2	1	
E03-07	139026600000	CYLINDER BLOCK GASKET	1	
E03-08	B090108014B0	PIN 8×14	2	


E04 VALVE MECHANISM SUB-ASSEMBLY



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E04-01	129076600000	INTAKE CAMSHAFT	1	
E04-02	B090105008AA	PIN 5×8	2	
E04-03	129036600000	DRIVEN TIMING SPROCKET	2	
E04-04	B0107060128H	BOLT M6×12	4	
E04-05	129086600000	EXHAUST CAMSHAFT	1	
E04-06	129246600320	VALVE LIFTER 3.20	8	
E04-06	129246600322	VALVE LIFTER 3.22	8	
E04-06	129246600334	VALVE LIFTER 3.34	8	
E04-06	129246600336	VALVE LIFTER 3.36	8	
E04-06	129246600360	VALVE LIFTER 3.60	8	
E04-06	129246600362	VALVE LIFTER 3.62	8	
E04-06	129246600364	VALVE LIFTER 3.64	8	
E04-06	129246600366	VALVE LIFTER 3.66	8	
E04-06	129246600368	VALVE LIFTER 3.68	8	
E04-06	129246600370	VALVE LIFTER 3.70	8	
E04-06	129246600372	VALVE LIFTER 3.72	8	
E04-06	129246600374	VALVE LIFTER 3.74	8	
E04-06	129246600376	VALVE LIFTER 3.76	8	
E04-06	129246600378	VALVE LIFTER 3.78	8	
E04-06	129246600380	VALVE LIFTER 3.80	8	
E04-06	129246600382	VALVE LIFTER 3.82	8	
E04-06	129246600384	VALVE LIFTER 3.84	8	
E04-06	129246600386	VALVE LIFTER 3.86	8	
E04-06	129246600388	VALVE LIFTER 3.88	8	
E04-06	129246600390	VALVE LIFTER 3.90	8	
E04-06	129246600392	VALVE LIFTER 3.92	8	
E04-06	129246600394	VALVE LIFTER 3.94	8	
E04-06	129246600396	VALVE LIFTER 3.96	8	
E04-06	129246600398	VALVE LIFTER 3.98	8	
E04-06	129246600400	VALVE LIFTER 4.00	8	
E04-06	129246600402	VALVE LIFTER 4.02	8	


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E04-06	129246600404	VALVE LIFTER 4.04	8	
E04-06	129246600406	VALVE LIFTER 4.06	8	
E04-06	129246600408	VALVE LIFTER 4.08	8	
E04-06	129246600410	VALVE LIFTER 4.10	8	
E04-06	129246600412	VALVE LIFTER 4.12	8	
E04-06	129246600414	VALVE LIFTER 4.14	8	
E04-06	129246600416	VALVE LIFTER 4.16	8	
E04-06	129246600418	VALVE LIFTER 4.18	8	
E04-06	129246600420	VALVE LIFTER 4.20	8	
E04-06	129246600422	VALVE LIFTER 4.22	8	
E04-06	129246600424	VALVE LIFTER 4.24	8	
E04-06	129246600426	VALVE LIFTER 4.26	8	
E04-06	129246600428	VALVE LIFTER 4.28	8	
E04-07	129226600000	PUNCH HEEL VALVE	16	
E04-08	129206600000	INTAKE ROCKER SHAFT	16	
E04-09	129256600000	SPRING	8	
E04-10	129216600000	VALVE SPRING SEAT	16	
E04-11	129186600000	INTAKE CHAIN WHEEL	4	
E04-12	129196600000	EXHAUST CHAIN WHEEL	4	
E04-15	129066600000	STOPPER	2	

E05 TIMING TENSIONING MECHANISM SYSTEM




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E05-01	149026600000	VICE GUIDE CHAIN PLATE	1	
E05-02	129026600000	TIMING CHAIN	1	
E05-03	149016600000	MAIN CHAIN PLATE COMPONENT	1	
E05-04	140106090000	O-RING2075 18.77×1.78	1	
E05-05	14903660BG01	TENSIONER ASSY	1	
E05-06	140076600000	PLUNGER SPRING	1	
E05-07	240036090000	SPACER 12.2×18×1	1	
E05-08	140116600000	SCREW PLUG	1	
E05-09	160306030040	BOLT M6×22	2	
E05-10	140126600000	MAIN CHAIN PLATE BOLT	1	

E06 PISTON,CONNECTING ROD & CRANKSHAFT ASSY



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E06-01	179156600000	RETAINING RING, PISTON PIN	4	
E06-02	179146580000	PIN, PISTON	2	
E06-03	179136580000	PISTON	2	
E06-04	170016600000	PISTON RING ASSY	2	
E06-05	179036580000	CONNECTING ROD COMPONENT	2	
E06-06	179096600010	BEARING SHELL, BROWN"	4	
E06-06	179096600020	BEARING SHELL, BLACK"	4	
E06-06	179096600030	BEARING SHELL, BLUE"	4	
E06-07	10009307011X	BOLT FOR REAMING HOLE M8×28	1	
E06-08	170106600000	WASHER 8×30×1.5	1	
E06-09	170096580010	CRANKSHAFT SPEED TRIGGER PLATE	1	
E06-10	179016580010	THE CRANKSHAFT COMPONENTS	1	
E06-11	179246600000	BALANCING SHAFT COMPONENTS	1	

This exploded view diagram illustrates the assembly of a mechanical component, likely a pump or engine part. The diagram shows the main housing (1) and its internal components, including a shaft (2), a rotor (3), and a stator (4). The rotor is shown in its assembled position (5) and in its exploded position (6). The stator is shown in its assembled position (7) and in its exploded position (8). The diagram also shows the assembly of the rotor and stator into the housing (9-11). The rotor is shown in its assembled position (12) and in its exploded position (13). The stator is shown in its assembled position (14) and in its exploded position (15). The diagram also shows the assembly of the rotor and stator into the housing (16-18). The rotor is shown in its assembled position (19) and in its exploded position (20). The stator is shown in its assembled position (21) and in its exploded position (22). The diagram also shows the assembly of the rotor and stator into the housing (23-25). The rotor is shown in its assembled position (26) and in its exploded position (27). The stator is shown in its assembled position (28) and in its exploded position (29). The diagram also shows the assembly of the rotor and stator into the housing (30-32). The rotor is shown in its assembled position (33) and in its exploded position (34). The stator is shown in its assembled position (35) and in its exploded position (36). The diagram also shows the assembly of the rotor and stator into the housing (37-39). The rotor is shown in its assembled position (40) and in its exploded position (41). The stator is shown in its assembled position (42) and in its exploded position (43). The diagram also shows the assembly of the rotor and stator into the housing (44-46). The rotor is shown in its assembled position (47) and in its exploded position (48). The stator is shown in its assembled position (49) and in its exploded position (50). The diagram also shows the assembly of the rotor and stator into the housing (51-53). The rotor is shown in its assembled position (54) and in its exploded position (55). The stator is shown in its assembled position (56) and in its exploded position (57). The diagram also shows the assembly of the rotor and stator into the housing (58-60). The rotor is shown in its assembled position (61) and in its exploded position (62). The stator is shown in its assembled position (63) and in its exploded position (64). The diagram also shows the assembly of the rotor and stator into the housing (65-67). The rotor is shown in its assembled position (68) and in its exploded position (69). The stator is shown in its assembled position (70) and in its exploded position (71).



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E07-01	159136600000	DOUBLE END STUD M10	1	
E07-02	159496540000	FUEL INJECTION NOZZLE	2	
E07-03	B190100800A0	O-RING 8×1.8	1	
E07-04	159256600000	INNER OIL PIPE ASSEMBLY	1	
E07-05	159186580000	AXLE SLEEVE	1	
E07-06	159196600000	AXLE SLEEVE PRESSING PLATE	1	
E07-07	B0107060146H	BOLT M6×14	1	
E07-08	B190103000B0	O-RING 30×2.65	1	
E07-09	B091404008B4	DOWEL PIN 6×8	1	
E07-10	159176600000	UPPER TANK OIL PLUG	1	
E07-11	B190100487A0	O-RING 4.87×1.8	1	
E07-12	B0205050086H	HEXAGON SOCKET HEEAD CAP SREW M5×8	4	
E07-13	159156600000	RESPIRATOR BAFFLE	1	
E07-14	159536600000	PARTITION PLATE AS-OIL CHAMBER	1	
E07-15	B0107050126H	BOLT M5×12	2	
E07-16	159566600000	TRIGGER COMPONENT	1	
E07-17	159106600000	BALANCE SHAFT PLAIN BEARING, BROWN"	4	
E07-17	159106600010	BALANCE SHAFT PLAIN BEARING, BLACK"	4	
E07-17	159106600020	BALANCE SHAFT PLAIN BEARING, BLUE"	4	
E07-18	159096600000	CRANKSHAFT PLAIN BEARING, BROWN"	6	
E07-18	159096600010	CRANKSHAFT PLAIN BEARING, BLACK"	6	
E07-18	159096600020	CRANKSHAFT PLAIN BEARING, BLUE"	6	
E07-19	269256600000	OIL FILTER	1	
E07-20	159476600000	OIL FINE FILTER ADAPTER	1	
E07-21	159126610000	PLUG 3/8	1	
E07-22	159586600000	OIL PRESSURE LOW PRESSURE ALARM	1	
E07-23	100053070001	O-RING 10×2	2	
E07-24	159656600000	TUBING ASSEMBLY II	1	
E07-25	159596600000	RELISF VALE ASSEMBLY	1	
E07-26	159406600000	LOWER BOX COVER	1	
E07-27	B0107060106H	BOLT M6×10	10	

NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E07-28	269266600000	GUIDE TUBE ASSEMBLY	1	
E07-29	269206600000	PRIMARY OIL FILTER ASSEMBLY	1	
E07-30	269216600000	SEALING RING	1	
E07-31	269306600000	O-RING 14×2.5	2	
E07-32	159496600000	TUBING ASSEMBLY I	1	
E07-33	159526600000	O-RING 5×2	2	
E07-34	B0205060086H	BOLT M6×8	1	
E07-35	269186600000	TUBING ASSEMBLY I PRESSING PLATE	1	
E07-36	159316600000	SHOCK ABSORBER	1	
E07-37	159446600000	BLOCKING BLOCK2	1	
E07-38	159436600000	BLOCKING BLOCK1	1	
E07-39	B0223060082H	HEXAGON SOCKET FLAT END FASTENING SCREW M6×8	1	
E07-40	219536600000	NEEDLE BEARING	1	
E07-41	159486600000	SPRING LOCATING PIN	1	
E07-42	B1212K301301	NEEDLE BEARING HK3013	1	
E07-43	159066600000	OUTPUT SHAFT OIL SEAL	1	
E07-44	159046600000	OUTPUT SHAFT BEARING LOCATING RING	1	
E07-45	159056600000	OUTPUT SHAFT BEARING 25×62×17	1	
E07-46	159306600000	OIL RETURN PIPE	1	
E07-47	159296600000	RUBBER TUBE 9×12×38	1	
E07-48	B1700012000A	CLAMP	2	
E07-49	159326600000	RESPIRATOR WELDING SUBASSEMBLY	1	
E07-50	B0107060226H	BOLT M6×22	2	
E07-51	150113820000	PLUG	1	
E07-52	15922660BG01	OIL OUTER PIPE	1	
E07-53	159856600000	O-RING 9×1.9	2	
E07-54	159146600000	BREATHER TUBE	1	
E07-55	159826600000	BOLT M8×120	1	
E07-56	159116600000	CARRIER RING 8	3	
E07-57	159836600000	BOLT M8×110	3	
E07-58	150083070000	DOWEL PIN 10×14	3	


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E07-59	159846600000	BOLT M8×50	1	
E07-60	B0107060386H	BOLT M6×38	6	
E07-61	B0107060326H	BOLT M6×32	1	
E07-62	159386600000	BOLT M9×113	4	
E07-63	159396600000	CARRIER RING 9	6	
E07-64	150316030110	BOLT M8×75	2	
E07-65	160306030120	BOLT M8×60	3	
E07-66	B0107060456H	BOLT M6×45	1	
E07-67	159716600000	BOLT M9×83	2	
E07-68	15902658BG01	BOX CLOSING MACHINING ASSEMBLY	1	

E08 GEAR SHIFT MECHANISM ASSEMBLY

NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E08-01	B0107060186H	BOLT M6×18	2	
E08-02	210056600010	CENTER SHIFT DURM	1	
E08-03	B12016180501	BERING 61805/P63	1	
E08-04	B090104008B0	CYLINDRICAL PIN 4(h6)×8	4	
E08-05	219056580000	DRUM GEARSHIFT	1	
E08-06	210066600000	WHEEL	1	
E08-07	B0205060186H	SCREW M6×18	1	
E08-08	219936600000	FILE DIAL BLOCK	1	
E08-09	219096600000	SHAFT, GEAR SHIFT	1	
E08-10	219106600000	DRIVEN SHAFT FORK	2	
E08-11	219596600000	BOLT M7×30	6	
E08-12	219626600000	BOLT M7×26	3	
E08-13	B0205060156H	BOLT M6×15	1	
E08-14	219396600000	SLEEVE	1	
E08-15	219336600000	SHIFT-SHIFT POSITIONING ROCKER ARM ASSEMBLY	1	
E08-16	219386600000	TORSIONAL SPRING	1	
E08-17	219376600000	WASHER	1	
E08-18	B0205060128H	SCREW M6×12	1	
E08-19	219636600000	BAFFLE	1	
E08-20	21956658BG01	CHANGE ROOM COVER	1	
E08-21	B0201060102H	SCREW M6×10	3	
E08-22	219646600000	BAFFLE	1	
E08-23	150103070002	PLUG	1	
E08-24	219616600000	STOPPER	1	
E08-25	B090108014B0	CYLINDRICAL PIN 8×14	3	
E08-26	159186580000	SLEEVE	1	
E08-27	219576600000	BERING 62×25×17	1	
E08-28	219586600000	BAFFLE	1	
E08-29	219086600000	SHAFT SHIFT FORK	1	
E08-30	219116600000	FORK, MAIN AXLE	1	
E08-31	219836600000	O_RING	1	FOR SHINING BLACK BIKE


NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E08-32	219826580000	COLLAR	1	
E08-33	219296600000	OUTPUT SPROCKET COMPONENTS	1	
E08-34	219316600000	WASHER	1	
E08-35	219846600000	NUT	1	
E08-36	219506600000	SEAL GASKET	1	
E08-37	219016600000	SHAFT, GEAR SHIFT	1	
E08-38	219536600000	ROLLING	1	
E08-39	219526600000	OIL SEAL	1	
E08-40	21949660BG01	VARIABLE SHAFT COVER	1	
E08-41	B0201060162H	CROSS RECESSED COUNTERSUNK HEAD SCREW M6×16	1	
E08-42	160306030090	BOLT M6×40	2	
E08-43	219916600000	O_RING 18×24	1	
E08-44	219516600000	SHIFT SENOR	1	
E08-45	160306030070	BOLT M6×30	4	
E08-46	219136580000	MAIN SHAFT UNIT	1	
E08-47	219216580000	DRIVE AXLE ASSY	1	

E09 OIL PAN ASSEMBLY




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E09-01	B0107060106H	BOLT M6×10	2	
E09-02	150066600000	PRESSING PLATE OF OIL PRIMARY STRAINER	1	
E09-03	150056600000	OIL PRIMARY STRAINER	1	
E09-04	150076600000	OIL PAN GASKET	1	
E09-05	15004660BG01	OIL PAN	1	
E09-06	B0107060256H	BOLT M6×25	10	
E09-07	150086600000	ABLASSSCHRAUBE GASKET	1	
E09-08	159506570000	ABLASSSCHRAUBE M12×22	1	

E10 ELECTR SYSTEM




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E10-01	249106600000	OVERRUNNING CLUTCH ASSY	1	
E10-02	299026600000	FLY WHEEL ASSY	1	
E10-03	B0205080188H	SCREW M8×18	3	
E10-04	B0205060306H	SCREW M6×30	3	
E10-05	B0703000060H	WASHER 6	3	
E10-06	299036600011	COIL ASSY	1	
E10-07	299086600000	WASHER 12	1	
E10-08	299096600000	BOLT M12×45	1	
E10-09	B0205060086H	SCREW M6×8	1	
E10-10	299126600000	PLATE	1	

E11 ELECTRIC STARTER ASSY




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E11-01	B0107060226H	BOLT M6×22	2	
E11-02	24901660BG01	STARTER MOTOR	1	
E11-03	249056600000	INTERMEDIATE GEAR SHAFT	2	
E11-04	249186600020	DUAL-GEAR	1	
E11-05	249046600000	INTERMEDIATE GEAR 1	1	
E11-06	249076600000	START GEAR ASSY	1	
E11-07	249206600000	WASHER	1	

E12 CLUTCH SYSTEM




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E12-02	209036600050	CLUTCH CENTER ASSY	1	
E12-03	209146600050	BOLT	3	
E12-04	209156600050	SPRING PRESSURE PLATE	1	
E12-05	209166600050	SPRING	3	
E12-06	209176600050	GASKET	3	
E12-07	209186600050	CLUTCH PRESSURE PLATE COMPONENT	1	
E12-08	209176600000	PULL PIN	1	
E12-09	219656600000	NUT	1	
E12-10	219666600000	SPRING GASKET 20	1	
E12-11	219926600000	GASKET 20.4×39.8×1	1	
E12-12	209196600050	FRICTION PLATE I	8	
E12-13	209206600050	CLUTCH PLATE II	1	
E12-14	209216600050	CLUTCH PLATE I	6	
E12-15	209236600050	SPRING GASKET	1	
E12-16	209246600050	SPRING SEAT	1	
E12-17	209256600050	CLUTCH CENTER	1	
E12-18	219686600000	GASKET 25.5×47×2.5	2	
E12-19	209126600050	CLUTCH HOUSING	1	
E12-20	219676600000	CLUTCH SLEEVE	1	

E13 LEFT COVER ASSY




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E13-01	160306030050	BOLT M6×25	8	
E13-02	169556600000	LEFT COVER PLATE	1	
E13-03	160306030080	BOLT M6×35	2	
E13-04	160306030200	BOLT M6×72	1	
E13-05	169356580000	CLAMP	1	
E13-06	169076600000	LEFT COVER GASKET	1	
E13-07	150043050000	LOCATING PIN	2	
E13-08	16902660MM01	LEFT COVER	1	

E14 RIGHT COVER ASSY




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E14-01	150043050000	LOCATING PIN	2	
E14-02	169116600000	RIGHT COVER GASKET	1	
E14-03	169216600010	TORSION SPRING	1	
E14-04	169226600000	SHIM	1	
E14-05	169326600020	LEVER AS-CONTROL	1	
E14-06	169376600000	OIL SEAL 20×12×5	1	
E14-07	B1212K121002	NEEDLE BEARING 12×16×10	2	
E14-08	16910660MM01	RIGHT COVER	1	
E14-09	169316600000	O-RING OF OIL FILLER HOLE COVER	1	
E14-10	169306600000	OIL FILLING HOLE COVER	1	
E14-11	160306030050	BOLT M6×TWENTY-FIVE	12	
E14-12	169286600000	OIL LEVEL MIRROR ASSEMBLY	1	
E14-13	169486600010	CLUTCH CABLE BRACKET	1	
E14-14	16926660MM01	ADJUSTING HOLE COVER	1	
E14-15	150293070000	O-RING SEAL 35×3	1	
E14-16	169166600000	OBSERVATION HOLE COVER	1	
E14-17	169246600000	SIGHT GLASS COVER O-RING	1	
E14-18	16030658PW10	RIGHT COVER HEAT SHIELD ASSEMBLY	1	
E14-19	160306030110	BOLT M6×50	2	
E14-20	160386580000	RIGHT COVER PLATE	1	
E14-21	160306030430	BOLT M6×48	2	
E14-22	160376580000	INSULATING SPONGE	1	
E14-23	58430PA80000	HARNESS BRACKET ASSEMBLY	1	
E14-24	92500P810001	BOND STRAP	1	

E15 COOLING SYSTEM




NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E15-01	279356600000	WATER PUMP BODY END FACE SEALING RING	1	
E15-02	B091404008B4	CYLINDRICAL PIN 4×8	3	
E15-03	279366600000	SEALING RING OF WATER PUMP BODY	1	
E15-04	279376600000	OIL SEAL ASSEMBLY 32×12×5	1	
E15-05	27934660BG01	WATER PUMP BODY	1	
E15-06	279326600000	SEALING RING OF WATER PUMP COVER	1	
E15-07	279606060000	WATER SEAL ASSEMBLY	1	
E15-08	279216600000	IMPELLER	1	
E15-09	170226090000	GASKET 6.5×12×1	2	
E15-10	B0107060226H	BOLT M6×22	1	
E15-11	27931660BG01	WATER PUMP COVER	1	
E15-12	160306030070	BOLT M6×30	2	
E15-13	160306030090	BOLT M6×40	3	
E15-14	160306030010	BOLT M6×12	1	

E16 OIL PUP SYSTEM



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E16-01	269056600000	THE OIL PUMP CHAIN	1	
E16-02	B0107060126H	BOLT M6×12	1	
E16-03	269196600000	SCREW M6×10	1	
E16-04	269316600000	THE OIL PUMP CHAIN TENSIONER ASSY	1	
E16-05	B0107060256H	BOLT M6×25	3	
E16-06	269066600000	THE OIL PUMP POINTS ASSEMBLY	1	

E17 THROTTLE VALVE SYSTEM



NO.	CODE	EN DESCRIPTION	QTY	REMARKS
E17-01	289016580010	VALVE BODY ASSEMBLY	1	
E17-02	289126580000	CABLE BRACKET	1	
E17-03	B1308050140H	SCREW COMBINATION M5×14	4	
E17-04	289146580000	CLAMP	2	
E17-05	289156580000	HOSE PIPE	1	
E17-06	289166580000	SCREW COMBINATION M6×20	1	
E17-07	289176580000	TEMPERATURE AND PRESSURE SENSOR	1	
E17-08	289206580000	O-RING	1	
E17-09	289216580000	STEPPER MOTOR	1	